



### ASSEMBLY FOR FLAT TOP STYLE MAGNIFYING GLASS

1. CUT WOOD 2 3/16"-LEAVING APPROXIMATLEY ¼ INCH OF THE BARE TUBE EXPOSED.
2. TURN TO DESIRED SIZE.
3. PUSH LARGE CENTER RING OVER EXPOSED TUBE.
4. PRESS IN HILT-VERY TIGHT-BE CAREFUL.
5. PLACE GLASS IN GLASS HOLDER AND SCREW GLASS HOLDER INTO THE HILT.
6. PRESS IN SMALL RING AND BLACK FINIAL.