



PERFUME PEN

TOOLING

MANDREL A

DRILL 5/16

BUSHING 8A

WOOD 5/8 X5/8 X ANY LENGTH

DRILLING AND TURNING

1. CUT WOOD BLANKS THE LENGTH OF BOTH TUBES - 1 SHORT 1 LONG.
2. DRILL HOLE THROUGH BOTH BLANKS.
3. EPOXY TUBE IN WOOD BLANKS.
4. MOUNT WOOD ON MANDREL WITH 2 BUSHINGS PER PEN BLANK.
5. TURN AND POLISH TO DESIRED SIZE. (BUSHINGS MATCH FINIALS)

ASSEMBLY

1. PRESS FINIALS IN ONE END OF EACH OF THE BLANKS.
2. SHORT BLANK- PRESS THREADED INSERT INTO OTHER END.
3. DROP WICK (LONG COTTON FILLED STRAW) INTO LONG BLANK.
4. PRESS NIB INTO OTHER END OF LONG BLANK. WHEN PRESSING IN NIB IT IS WISE TO USE A BLOCK OF WOOD WITH A HOLE IN IT SO FLANGE IS FLAT ON WOOD.
5. INSERT APPLICATOR TIP.

LOADING PERFUME PEN WITH PERFUME THE TRADITIONAL WAY TO FILL THE PEN IS TO DIP THE APPLICATOR TIP WHILE ON THE PEN INTO THE PERFUME BOTTLE AND HOLD FOR ABOUT A MINUTE. THE LONG WHITE WICK IS USUALLY NOT FILLED. THIS SHOULD LAST ABOUT 1-2 MONTHS OF NORMAL USE. ALSO NOTE THE WHITE APPLICATOR TIP MAY BE LOOSE IN THE NIB BEFORE FILLING-THIS IS PLANNED AS THE TIP SWELLS WHEN FILLED.

CLEANING/CHANGING PERFUME

TO CLEAN OR CHANGE TO A NEW PERFUME REMOVE THE APPLICATOR TIP AND SOAK IN PHARMACY TYPE ALCOHOL (NOT HARDWARE STORE WOOD ALCOHOL).

PERFUME PENS CAN BE TURNED INTO ANY SHAPE DESIRED. VASE SHAPE, ETC. 08/99