
#BereattareWoodsco.,inc.

18745 Sheldon Rd. Middleburg Hts., Ohio 44130 (216) 898-8956 (216) 898-8962 Fax N° 9 ALLEY 1, Lane 90 Chiu Chiong Lu Chou Taipei Hsien Taiwan R.O.C. Ph: (02) 2281-8293 Fax: 886-2-2281-8818 Manufacturers of

Quality Writing Instruments

Related Accessories - Premium Gifts - Custom Designs

bereahard@aol.com www.penkits.com



MINI MAGNIFYING GLASS

Tooling: A-Mandrel #1A Bushing J Bit

Cutting and Turning

Cut wood length of tube or a little longer to square off.

- 2. Using 7mm pen bushing (1A) you can make 3-4 blanks at a time.
- 3. Turn to bushing or desired size.
- 4. Sand and polish.

ASSEMBLY

- 1. Push finial into one end of blank.
- 2. Push hilt of glass holder into other end.
- 3. Put magnifying glass into groove of glass holder.
- 4. Screw glass holder into threaded end of hilt.
- 5. Thread chain through hole.

Helpful Hint: If glass is not tight use a very small bead of super glue in groove of glass holder. 10/03